


# Flip-flop: S-R nand-gated unclocked



Flip-flop: S-R nand-gated unclocked..... 1

1 Description ..... 1

    1.1 Pins..... 1

    1.2 Parameters ..... 1

    1.3 Input..... 2

    1.4 Output..... 2

    1.5 Representation ..... 2

## 1 Description

This device is an implementation of an unclocked nand-gated S-R flip-flop without override controls. For a version with the override controls, use the device "S-R nand-gated unclocked full".

### 1.1 Pins

This device has four pins:

<i>pin</i>	<i>type</i>	<i>description</i>
S	input	S input
R	input	R input
Q	output	Q output
notQ	output	notQ output

### 1.2 Parameters

The initial value of Q must be defined if the device is possibly toggling at  $t=0$ . When the device operates in clearing or setting mode at  $t=0$ , the initial value is ignored.

The value of the *stepped\_mode* flag determines whether the device operates in *stepped* or *ramped* mode. In *stepped* mode (the default for ideal logical signals), the outputs are represented as stepped signals, where changes in value are observed as vertical steps at the time they occur. In *ramped* mode, the value transitions of the outputs are seen as ramps between  $t-\Delta t$  and  $t$ .

<i>parameter</i>	<i>description</i>
Q_ini	initial value of Q if holding or toggling at $t=0$
stepped_mode	=1 to indicate stepped mode (default) =0 to indicate ramped mode

### 1.3 Input

The input pins may be connected to any control signals.

Numerical input values are automatically interpreted as logical values by this device, as follows:

<i>input</i>	<i>converted logical value</i>	<i>logical value representation</i>
value > 0	true	1
value ≤ 0	false	0

### 1.4 Output

The outputs are  $Q$  and its logical inverse  $notQ$ . Their representation as *stepped* or *ramped* signals is determined by the value given to the parameter *stepped\_mode*.

The numerical representation of the output logical values is:

<i>output logical value</i>	<i>output numerical value</i>
true	1
false	0

### 1.5 Representation

The implementation of the model can be inspected by opening the device's subcircuit.

The model applies the following logic for determining its state:

<i>rule sequence</i>	<i>action</i>	<i>output</i>
if S>0 and R>0	setting	$Q(t) = 1$
else if S<=0 and R<=0	holding	$Q(t) = Q(t-\Delta t)$
else if S>0	setting	$Q(t) = 1$
else if S<=0	clearing	$Q(t) = 0$
endif		
if holding at t=0	use Q_ini	$Q(0) = Q\_ini$